





MODEL 131L PLANETARY GEAR DRIVE SERVICE MANUAL



WARNING: While working on this equipment, use safe lifting procedures, wear adequate clothing and wear hearing, eye and respiratory protection.

THIS SERVICE MANUAL IS EFFECTIVE:
S/N: 351373 TO CURRENT
DATE: 09/25/2024 TO CURRENT
VERSION: SM131LA2-AA

NOTE: Individual customer specifications (mounting case, output shaft, brake assembly, etc.) may vary from exploded drawing and standard part numbers shown. If applicable, refer to customer drawing for details.



131L SINGLE STAGE GEAR DRIVE


| | GROUP | QTY | MODEL 131L DESCRIPTION | RATIOS | |
|--------------|-------|-----|--------------------------------------|-----------------|-----------------|
| | | | | 4:1 (4.42:1) | 6:1 (6.00:1) |
| BASE | 1 | 1 | A2 - ROUND FLANGE | 13-004-3268 | |
| | | | C- CUSTOM | | |
| OUTPUT SHAFT | 2 | 1 | D8 - Ø3.00 X 5/8" KEY | 13-004-4680M | |
| | | | D10 - 20T 8/16DP SPLINE X 2.12" LONG | 13-004-4678M | |
| | | | D11 - 23T 8/16DP SPLINE X 2.25" LONG | 13-004-4682M | |
| | | | H2 - 2 1/2" HEX | 13-004-4684M | |
| | | | S3 - 8X Ø5/8-11 UNC ON Ø9.500 B.C. | 13-004-4666M | |
| | | | S5 - 8X Ø5/8-11 UNC ON Ø6.000 B.C. | 13-004-4629M | |
| | | | S6 - 8X Ø11/16 ON Ø9.000 B.C. | 13-004-4668M | |
| COVER | 3 | 1 | C1 - CUSTOM SHAFT | | |
| | | | SAE 'A' 2 & MOD 4 BOLT W/CODE 4 | 13-004-1252 | |
| | | | SAE 'B' 2 & 4 BOLT W/ CODE 4 | 13-004-1202 | |
| | | | SAE 'C' 2 & 4 BOLT | 13-004-1212 | |
| INPUT GEAR | 4 | 1 | SAE 'D' 4 BOLT W/ CODE 9 | 13-004-1412 | |
| | | | CODE 4 - INPUT 14T 12/24DP | 13-004-1372 | 13-004-1382 |
| | | | CODE 7 - INPUT 17T 12/24 DP | 13-004-1482 | 13-004-1392 |
| | 5 | (1) | CODE 9 - INPUT 13T 8/16DP ** | 13-004-1402 | 13-004-1512 |
| | | | CARRIER ASSEMBLY | 13-005-2001 | 13-005-2011 |
| | | | CARRIER | 13-004-1062 | 13-004-1072 |
| | 5A | 1 | PLANET GEAR | 13-004-1082 | 13-004-1092 |
| | 5B | 3 | PLANET SHAFT | 81-004-0061 | |
| | 5C | 6 | PLANET BEARING | 01-105-0500 | |
| | 5D | 6 | PLANET THRUST WASHER | 81-004-1561 | |
| | 5E | 3 | ROLL PIN | 01-153-0210 | |
| | 5F | 3 | RING GEAR | 81-004-2362 | |
| | 12 | 1 | THRUST WASHERS | ---- | |
| | 14 | 1 | CARRIER THRUST WASHER ** | 81-004-2711 | |
| | 14A | 1 | THRUST RACE ** | 01-112-0030 | |
| | 14B | 1 | INPUT THRUST WASHER ** | 81-004-2883 | |
| | 14C | 1 | SEAL KIT | 13-016-2101 | |
| | 16 | 1 | SHAFT SEAL | 01-405-0690 | |
| | 16A | 2 | O-RING | 01-402-0420 | |
| | 20 | 1 | OUTPUT SHAFT BEARINGS | ---- | |
| | 20A | 1 | OUTER CONE | 01-102-0260 | |
| | 20B | 1 | OUTER CUP | 01-103-0260 | |
| | 20C | 1 | INNER CONE | 01-102-0030 | |
| | 20D | 1 | INNER CUP | 01-103-0030 | |
| | 25 | 1 | HARDWARE | ---- | |
| | 25A | 8 | HHCS (3/8 X 1 1/2) ** | 01-150-1670 | |
| | 25B | 16 | 12PT CBORE (1/2 X 1.25) | 01-150-1460 | |
| | 25G | 8 | LOCK WASHER ** | 01-166-0010 | |
| | 25H | 16 | HARD WASHERS | 01-166-0120 | |
| | 30 | 1 | PLUGS/GREASE ZERK | ---- | |
| | 30A | 1 | PIPE PLUG (3/8 NPT MAGNETIC) ** | 01-207-0070 | |
| | 30B | 2 | PIPE PLUG (1/2 NPT MAGNETIC) | 01-207-0041 | |
| | 30C | 1 | PIPE PLUG (1/8 NPT HOLLOW HEX) | 01-207-0030 | |
| | 30D | 1 | GREASE ZERK 1/8 NPT | 01-215-0010 | |
| | 35 | 1 | MISCELLANEOUS | ---- | |
| | 35A | * | SHIMS | 80-004-1151 | |
| | 35B | 1 | SPLIT RING | 81-004-8101 | |
| | 35C | 1 | LOCK RING | 81-004-8111 | |
| | 35D | 1 | RETAINING RING ** | 01-160-0040 | |

GENERIC 131L SINGLE STAGE GEAR DRIVE ECN: - REV: A 03/07/2025 JH

NOTES:

1. *QUANTITY DEPENDANT UPON DESIRED BEARING PRELOAD

2. ** 'D' COVER IS SOLD ONLY W/CODE 9 INPUT AS A SINGLE. REPLACE 14C WITH 01-112-0030, 14B WITH 01-112-0400, 30A WITH 01-207-0041, 25A & 25G WITH (8) 01-150-1710. REMOVE 14A & 35D






131L DOUBLE STAGE GEAR DRIVE

| | GROUP | QTY | MODEL 131L DESCRIPTION | RATIOS | | | | | |
|--------------|-------|-----|--------------------------------------|-------------------|-------------------|-------------------|---------------------------------|--------------------------------|-------------------|
| | | | | 19:1 (19.54:1) | 26:1 (26.52:1) | 33:1 (33.15:1) | W/O CODE 4 36:1 (36.00:1) | W/ CODE 4 36:1 (36.00:1) | 45:1 (45.00:1) |
| BASE | 1 | 1 | A2 - ROUND FLANGE | 13-004-3268 | | | | | |
| | | | C- CUSTOM | | | | | | |
| OUTPUT SHAFT | 2 | 1 | D8 - Ø3.00 X 5/8" KEY | 13-004-4680M | | | | | |
| | | | D10 - 20T 8/16DP SPLINE X 2.12" LONG | 13-004-4678M | | | | | |
| | | | D11 - 23T 8/16DP SPLINE X 2.25" LONG | 13-004-4682M | | | | | |
| | | | H2 - 2 1/2" HEX | 13-004-4684M | | | | | |
| | | | S3 - 8X 5/8-11 UNC ON Ø9.500 B.C. | 13-004-4666M | | | | | |
| | | | S5 - 8X 5/8-11 UNC ON Ø6.000 B.C. | 13-004-4629M | | | | | |
| | | | S6 - 8X 11/16 ON Ø9.000 B.C. | 13-004-4668M | | | | | |
| COVER | 3 | 1 | C1 - CUSTOM SHAFT | | | | | | |
| | | | SAE 'A' 2 & MOD 4 BOLT | 13-004-1192 | 13-004-1222 | 13-004-1192 | --- | 13-004-1222 | |
| | | | SAE 'A' 2 & MOD 4 BOLT W/CODE 4 | 13-004-1252 | 13-004-1222 | --- | --- | 13-004-1222 | |
| | | | SAE 'B' 2 BOLT | 13-004-1182 | 13-004-1232 | 13-004-1182 | --- | 13-004-1232 | |
| | | | SAE 'B' 2 & 4 BOLT W/ CODE 4 | 13-004-1202 | 13-004-1232 | --- | --- | 13-004-1232 | |
| INPUT GEAR | 4 | 1 | SAE 'C' 2 & 4 BOLT | 13-004-1212 | 13-004-1242 | 13-004-1212 | --- | 13-004-1242 | |
| | | | CODE 2 - INPUT 13T 16/32 DP SPLINE | 13-004-1292 | 13-004-1312 | 13-004-1302 | --- | 13-004-1312 | |
| | | | CODE 3 - INPUT 1" 6 B SPLINE | 13-004-1322 | 13-004-1472 | 13-004-1332 | --- | 13-004-1472 | |
| | | | CODE 4 - INPUT 14T 12/24 DP SPLINE | 13-004-1342 | 13-004-1362 | --- | --- | 13-004-1352 | 13-004-1362 |
| | | | CODE 5 - INPUT 15T 16/32 DP SPLINE | 13-004-1452 | 13-004-1802 | 13-004-1442 | --- | 13-004-1802 | |
| 5 | (1) | | CARRIER ASSEMBLY - SECONDARY | 13-005-2001 | 13-005-2011 | 13-005-2001 | --- | 13-005-2011 | |
| 5A | 1 | | CARRIER - SECONDARY | 13-004-1062 | 13-004-1072 | 13-004-1062 | --- | 13-004-1072 | |
| 5B | 3 | | PLANET GEAR - SECONDARY | 13-004-1082 | 13-004-1092 | 13-004-1082 | --- | 13-004-1092 | |
| 5C | 3 | | PLANET SHAFT - SECONDARY | 81-004-0061 | | | | | |
| 5D | 6 | | PLANET BEARING | 01-105-0500 | | | | | |
| 5E | 6 | | PLANET THRUST WASHER | 81-004-1561 | | | | | |
| 5F | 3 | | ROLL PIN | 01-153-0210 | | | | | |
| 6 | 1 | | SUN GEAR | 13-004-1142 | 13-004-1152 | 13-004-1142 | --- | 13-004-1152 | |
| 7 | (1) | | CARRIER ASSEMBLY - PRIMARY | 13-005-2021 | 13-005-2041 | 13-005-2031 | --- | 13-005-2041 | |
| 7A | 1 | | CARRIER - PRIMARY | 13-004-1032 | 13-004-1052 | 13-004-1042 | --- | 13-004-1052 | |
| 7B | 3 | | PLANET GEAR - PRIMARY | 13-004-1102 | 13-004-1122 | 13-004-1112 | --- | 13-004-1122 | |
| 7C | 3 | | PLANET SHAFT - PRIMARY | 13-004-1021 | | | | | |
| 7D | 6 | | PLANET BEARING | 01-105-0590 | | | | | |
| 7E | 6 | | PLANET THRUST WASHER | 81-004-1561 | | | | | |
| 7F | 3 | | ROLL PIN | 01-153-0180 | | | | | |
| 12 | 1 | | RING GEAR | 81-004-2362 | | | | | |
| 14 | | | THRUST WASHERS | --- | | | | | |
| 14A | 1 | | CARRIER THRUST WASHER | 81-004-2711 | | | | | |
| 14B | 1 | | CARRIER THRUST WASHER | --- | 81-004-2711 | --- | --- | 81-004-2711 | |
| 14C | 1 | | CUP WASHER | 81-004-2701 | --- | 81-004-2701 | --- | --- | |
| 14G | 2 | | THRUST RACE | --- | 01-112-0230 | --- | --- | 01-112-0230 | |
| 14L | 1 | | THRUST BEARING | --- | 01-112-0220 | --- | --- | 01-112-0220 | |
| 16 | (1) | | SEAL KIT | 13-016-2101 | | | | | |
| 16A | 1 | | SHAFT SEAL | 01-405-0690 | | | | | |
| 16B | 2 | | O-RING | 01-402-0420 | | | | | |
| 20 | | | OUTPUT SHAFT BEARINGS | --- | | | | | |
| 20A | 1 | | OUTER CONE | 01-102-0260 | | | | | |
| 20B | 1 | | OUTER CUP | 01-103-0260 | | | | | |
| 20C | 1 | | INNER CONE | 01-102-0030 | | | | | |
| 20D | 1 | | INNER CUP | 01-103-0030 | | | | | |
| 25 | | | HARDWARE | --- | | | | | |
| 25A | 8 | | HHCS (3/8 X 1 1/2) | 01-150-1670 | | | | | |
| 25B | 16 | | 12PT CBORE (1/2 X 1.25) | 01-150-1460 | | | | | |
| 25G | 8 | | LOCK WASHER | 01-166-0010 | | | | | |
| 25H | 16 | | HARD WASHERS | 01-166-0120 | | | | | |
| 30 | | | PLUGS/GREASE ZERK | --- | | | | | |
| 30A | 1 | | PIPE PLUG (3/8 NPT MAGNETIC) | 01-207-0070 | | | | | |
| 30B | 2 | | PIPE PLUG (1/2 NPT MAGNETIC) | 01-207-0041 | | | | | |
| 30C | 1 | | PIPE PLUG (1/8 NPT HOLLOW HEX) | 01-207-0030 | | | | | |
| | | | GREASE ZERK 1/8 NPT | 01-215-0010 | | | | | |
| 35 | | | MISCELLANEOUS | --- | | | | | |
| 35A | * | | SHIMS | 80-004-1151 | | | | | |
| 35B | 1 | | SPLIT RING | 81-004-8101 | | | | | |
| 35C | 1 | | LOCK RING | 81-004-8111 | | | | | |


*QUANTITY DEPENDANT UPON DESIRED BEARING PRELOAD
131L DOUBLE STAGE GEAR DRIVE ECN: - REV: A 09/18/2024 JH



LUBRICATION & MAINTENANCE

Using the chart below, determine an appropriate lubricant viscosity. Use only EP (extreme pressure) or API GL-5 designated lubricants. Change the lubricant after the first 50 hours of operation and at 500 hour intervals thereafter. The gear drive should be partially disassembled to inspect gears and bearings at 1000 hour intervals.







Recommended ambient and operating temperatures for conventional and synthetic gear lubricants



Note: Ambient temperature is the air temperature measured in the immediate vicinity of the gearbox. A Gearbox exposed to the direct rays of the sun or other radiant heat sources will operate at higher temperatures and therefore must be given special consideration. The max operating temp must not be exceeded under any circumstances, regardless of ambient temperature.

If your unit was specified "shaft up" or with a "-Z" option, a grease zerk was provided in the base housing. For shaft-up operation, the output bearing will not run in oil and must be grease lubricated. Use a lithium based or general purpose bearing grease sparingly every 50 operating hours or at regular maintenance intervals. Over-greasing the output bearing should be avoided as it tends to fill the housing with grease and thicken the oil.

ESKRIDGE MODEL 131LA2 OIL CAPACITIES

| Operating Position | | Oil Capacity | | | Oil Level | |
|---|------------------------------|-----------------|-----------------|-----------------|--|---|
| | | Single stage | Double stage | Triple stage | | |
|  | Horizontal Shaft | 3.0 pt / 1.42 L | 3.0 pt / 1.42 L | 4.1 pt / 1.94 L | To horizontal centerline of gear drive |  |
|  | Vertical Shaft (Pinion Up) | 5.0 pt / 2.37 L | 5.0 pt / 2.37 L | 6.9 pt / 1.5 L | To side port on gear drive base |  |
|  | Vertical Shaft (Pinion Down) | 5.0 pt / 2.37 L | 5.0 pt / 2.37 L | 6.9 pt / 1.5 L | To midway on upper/primary gear set |  |

ESKRIDGE PART NUMBER INTERPRETATION

Note: All non-custom Eskridge Geardrives are issued a descriptive part number which includes information regarding the Model, means of shaft retention, base style, shaft style, input mounting, input shaft size, overall ratio and various available options. For a detailed breakdown of this information, please refer to Eskridge product specification sheets found at: <http://www.eskridgeinc.com/geardrives/gearprodspecs.html>

Unit Teardown

- 1) Scribe a diagonal line across the outside of the unit from the cover (3) to the base (1) before disassembly to aid in the proper positioning of pieces during reassembly.
- 2) Remove drain plugs (30A, 30B) and drain oil from unit. The oil will drain out more quickly and completely if warm.
- 3) Remove the eight 3/8-16 capscrews (25A) and lockwashers (25G) securing the cover (3).
- 4) Remove the cover (3), thrust washer (14B or 14G, 14L), and input gear (4). Inspect o-ring (16B); discard if damaged or deformed.
- 5) Lift the primary planet carrier assembly (7) out of the unit. For a single stage unit remove retaining ring (35D) and thrust washer (14C).
- 6) Only if the ring gear (12) needs to be replaced remove the sixteen 1/2-13 capscrews (25B) and lockwashers (25H) securing the ring gear (12). Remove ring gear (12).
- 7) For double stage remove sun gear (6).
- 7) Remove secondary carrier assembly (5), and thrust washer (14B, or 14A). Inspect o-ring (16B), and discard if damaged or deformed.
- 8) The unit is now separated into subassemblies. The area(s) requiring repair should be identified by thorough inspection of the individual components after they have been cleaned and dried.

- 4) Remove planet gears (5B), thrust washers (5E), and bearings (5D) from the carrier (5A).
- 5) Inspect the planet gear (5B) bearing bores, planet shafts (5C) and bearings (5D). Check for spalling, bruising or other damage. Replace components as necessary.
- 6) Use pin punch to remove roll pins (5F) from planet shafts (5C).

Reassembly

- 1) Insert bearings (5D) into planet gear (5B). Place a planet washer (5E) on top and bottom of planet gear and slide into carrier (5A).
- 2) Install planet shaft (5C) with chamfered end of roll pin hole toward outside diameter of the carrier (5A). This will aid in alignment of holes while inserting roll pin (5F).
- 3) Drive roll pin (5F) into the carrier (5A) hole and into the planet shaft (5C) until flush to the outside diameter of the carrier. Repeat for remaining planet gears.

Primary Carrier Subassembly


(Items 7A, 7B, 7C, 7D, 7E, 7F)

Follow the same procedure as for the secondary carrier assembly. Substitute items as indicated: carrier (7A), planet gears (7B), planet shafts (7C), bearings (7D), thrust washers (7E), and roll pins (7F).

NOTE: This does not apply to single-stage units.

Secondary Carrier Subassembly

(Items 5A, 5B, 5C, 5D, 5E, 5F)




Disassembly

- 1) Rotate planet gears (5B) to check for abnormal noise or roughness in bearings (5D) or planet shafts (5C). If further inspection or replacement is required, proceed as follows.


NOTE: Support only the carrier (5A) while pressing out planet shafts (5C).

- 2) Drive roll pins (5F) completely into the planet shafts (5C).
- 3) Press or drive planet shafts (5C) out of carrier (5A).



Base Subassembly

(Items 1, 2, 16A, 20A, 20B, 20C, 20D, 30C, 35A, 35B, 35C,)



Disassembly

- 1) Remove the lock ring (35C) using a heel bar or puller. Be careful not to pry against the bearing cage (20C). Remove split ring segments (35B) and shims (35A).

Caution: Since the output shaft is no longer retained, care should be taken to avoid personal injury. Care should also be taken not to damage the shaft while pressing through base.

Note: Removing the shaft from the base assembly damages the shaft seal (16A) and the seal will need to be replaced.

- 2) Base (1) should be set shaft side down, as shown, on a plate or table. Press output shaft (2) through the bottom of base by

applying a load to top end (internal end) of shaft until it passes through inner bearing cone (20C).

- 3) A gear puller or bearing splitter may be used to remove the outer bearing cone (20A) from the shaft (2). If reusing old bearing cone, do not pull on or damage roller cage. Remove the shaft seal (16A) for replacement.
- 4) Inspect inner and outer bearing cups (20D & 20B). If cups are damaged, drive them out using a brass drift or remove with a puller.

Reassembly

- 1) Place base (1) (output side up, opposite shown) on the table.
- 2) Apply a layer of lithium or general purpose bearing grease to the roller contact surface of outer bearing cup (20B).
- 3) Press outer bearing cone (20A) (large end down as shown) onto the shaft (2) until it seats against the shoulder.

Note: Press bearing cone onto output shaft by pressing on inner race only. DO NOT press on roller cage, as it may damage bearing.

- 4) Place shaft (2) with the outer bearing cone (20A) into base (1).
- 5) Flip this assembly, resting it on the end of the output shaft (2).
- 6) Apply a layer of lithium or general purpose bearing grease to the roller contact surface of the inner bearing cup (20D). Press the inner bearing cone (20C) (large end up as shown) onto the shaft (2) until it is seated against inner bearing cup (20D).
- 7) Prior to installation of the shaft seal (16A), the bearing preload may result in a rolling torque that varies between 50 and 100 in-lb. The bearing preload should be tailored to your application; a low-speed application may require a high pre-load, high-speed applications usually benefit from low pre-load. Adding shims (35A) will increase the pre-load on the bearing set. Determine your pre-load requirement and install shims to obtain this pre-load. Install the Load-N-Lock segments (35B) over the shims and into the groove in the output shaft. With the Load-N-Lock segments firmly installed, press lock ring (35C) over the segments.
- 8) Flip the assembly over. Lubricate inner lip of shaft seal (16A). Use a soft hammer or press tool to install shaft seal until it is flush with the base (1). It should be installed with the open side of the seal toward the inside of the unit.

All subassembly service or repairs should be complete at this time. Continue to Unit Assembly to complete unit buildup.

Unit Assembly

- 1) When all subassemblies are complete, the unit is ready to be assembled.
- 2) Lubricate o-ring **(16B)** and install on the pilot of the base **(1)**.
- 3) Install the secondary carrier assembly **(5)** onto the output shaft **(2)**. Align the splines of the carrier **(5A)** with the splines of the shaft and slide the carrier onto the shaft..

Caution: Hold ring gear(s) (12) by outside diameter or use lifting device to prevent injury

- 4) Align teeth of ring gear **(12)** with planet gear **(5B)** teeth. Place ring gear on base **(1)** and align mounting holes. Use the scribed line made during disassembly for reference.
- 5) Install the sixteen 1/2-13 capscrews **(25B)** and lockwashers **(25H)** and torque to **110 ft-lb dry, 80 ft-lb if the fasteners are lubricated.**
- 5) For two stage install sun gear **(6)** into carrier assembly **(5)** and thrust washer **(14B or 14A, 14B, 14C, 35D if equipped)** on top of carrier.
- 6) Install primary carrier assembly **(7)**. Align carrier **(7A)** spline teeth with sun gear **(6)** spline teeth. For single stage install retaining ring **(35D)** and thrust washer **(14C)**.
- 7) Install input gear **(4)** into primary carrier assembly **(7)** and thrust washer **(14B, or 14G, 14L if equipped)** on top of carrier **(7A)**. For single stage install retaining ring **(35D)** and washer and input thrust was **(14C)**.
- 8) Lubricate o-ring **(16B)** and install on cover **(3)** pilot. Noting the scribed line made during disassembly, install the cover.
- 9) Install the hex-head capscrews **(25A)** with lockwashers **(25G)**. **Torque the capscrews to 45 ft-lb dry or 35 ft-lb if the fasteners are lubricated.**
- 10) Ensure the unit spins freely by using a splined shaft to drive the input gear **(4)**.
- 11) Install drain plugs **(30A, 30B)**, using pipe sealant on threads.
- 12) Fill the unit with GL5 EP 80/90 gear oil to the proper level, as specified, using the oil fill hole in the cover **(3)**.

The gearbox is now ready to use.